

## **SeCorrPhon** **AC 200 receiver**



11.01.2018 a – 107618 – en

Quick reference guide  
Switching between  
AQUAPHON A 200 and SeCorr C 200

## 1 Purpose

**SeCorrPhon** is a system for locating water leaks and water pipes.

The **SeCorrPhon** system can be used for:

- Acoustic leak detection
- Acoustic pipeline location
- Correlative leak detection

## 2 Intended use

The **SeCorrPhon** system is intended for professional industrial and commercial use. The appropriate specialist knowledge is required to operate the system.

The system must only be used for the applications specified in Section 1.

## 3 Functional areas

The **AC 200** receiver has two functional areas. Acoustic location is carried out in the **AQUAPHON A 200** functional area; correlative location in the **SeCorr C 200** functional area.

---

### Note:

The following documents explain how to use the system and operate the receiver in the different functional areas:

- **AQUAPHON A 200** operating instructions
  - **SeCorr C 200** operating instructions
- 

The receiver is used to toggle between the two functional areas.

The **AC 200** receiver will remain in the last functional area when you switch it off and back on again.

Settings in the different functional areas are independent of one another.

### 3.1 Switching from AQUAPHON to SeCorr

Starting point:

- The system is ready for use.
- The receiver is in the **AQUAPHON A 200** functional area.

The main view is open.

1. Tap the **Settings** button. The **Settings** menu appears.
2. Tap the **Application** button. The **Application** menu appears.
3. Tap the **Correlation** button. The receiver switches to the **SeCorr C 200** functional area.

### 3.2 Switching from SeCorr to AQUAPHON

Starting point:

- The system is ready for use.
- The receiver is in the **SeCorr C 200** functional area.

The main view is open.

1. Tap the **Settings** button. The **Settings** menu appears.
2. Tap the **Application** button. The **Application** menu appears.
3. Select the desired application. The receiver switches to the **AQUAPHON A 200** functional area.



**Hermann Sewerin GmbH**

Robert-Bosch-Straße 3  
33334 Gütersloh, Germany  
Tel.: +49 5241 934-0  
Fax: +49 5241 934-444  
[www.sewerin.com](http://www.sewerin.com)  
[info@sewerin.com](mailto:info@sewerin.com)

**SEWERIN SARL**

17, rue Ampère – BP 211  
67727 Hoerdt Cedex, France  
Tél. : +33 3 88 68 15 15  
Fax : +33 3 88 68 11 77  
[www.sewerin.fr](http://www.sewerin.fr)  
[sewerin@sewerin.fr](mailto:sewerin@sewerin.fr)

**SEWERIN IBERIA S.L.**

Centro de Negocios "Eisenhower"  
Avenida Sur del Aeropuerto  
de Barajas 28, Of. 2.1 y 2.2  
28042 Madrid, España  
Tel.: +34 91 74807-57  
Fax: +34 91 74807-58  
[www.sewerin.es](http://www.sewerin.es)  
[info@sewerin.es](mailto:info@sewerin.es)

**Sewerin Ltd**

Hertfordshire  
UK  
Phone: +44 1462-634363  
[www.sewerin.co.uk](http://www.sewerin.co.uk)  
[info@sewerin.co.uk](mailto:info@sewerin.co.uk)

**Sewerin Sp.z o.o.**

ul. Twórcza 79L/1  
03-289 Warszawa, Polska  
Tel.: +48 22 675 09 69  
Tel. kom.: +48 501 879 444  
[www.sewerin.pl](http://www.sewerin.pl)  
[info@sewerin.pl](mailto:info@sewerin.pl)